

PLEASANT VALLEY SUBDIVISION (0746)

Mile Post	Rule 6.3	CP #'s	Radio Display: End of Track to Colton -2323		Sta. #'s	Siding Feet
			WEST ▼ STATIONS	EAST ▲		
21.1	YL		END OF TRACK (1.0)		Y	
19.5			SKYLINE (2.0)		Y UW720	12600
17.5			VALCAM (2.3)		Y UW718	7690
15.2	TWC		SCOFIELD (15.2)		UW715	
0.0	YL		COLTON		Y UW093	
(21.1)						
SI-01 MAIN TRACK AUTHORITY						
TWC Between MP 1.0 and MP 16.0. Yard Limits Between MP 0.0 and MP 1.0; MP 16.0 and MP 21.1.						
SI-02 MAXIMUM SPEED TABLE						
Maximum Speed			MPH			
Between Mileposts 21.1 and 0.0						
(Except as Below)						
			20			
21.1 and 19.5.....			10			
19.5 and 1.0 W.....			15			
SI-03 OTHER SPEED RESTRICTIONS						
Maximum Speed			MPH			
1. Thru Sidings & Turnouts						
			All Sidings..... 10			
2. Dual Control Switch Turnouts (No Exceptions.)						
3. Misc. Speed Restrictions (No Exceptions.)						
SI-04 MAIN TRACK DESIGNATIONS - None.						
SI-05 MILEPOST EQUATIONS - None.						
SI-06 DTC BLOCK LIMITS - None.						
SI-07 ITEM 13 TRAIN DEFECT DETECTORS						
%		0.6		%		9.5
%		2.0		%		10.9
%		3.5		%		14.0
%		5.1		%		16.9
%		6.4				
%		8.1				
SI-08 RULES ITEMS						
Rule 31.7.1 When dynamic brake is inoperative, retainers must be set in slow direct position on all cars Skyline to Colton.						
SI-09 FRA EXCEPTED TRACKS - None.						
SI-10 BUSINESS TRACKS - None.						
SI-11 INDUSTRIAL LEADS - None.						
SI-12 TONNAGE RESTRICTIONS/TPOB						
Maximum gross weight: 143 Tons.						
SI-13 TRAIN MAKE-UP RESTRICTIONS - None.						

<p>SI-14 MISC. INSTRUCTIONS</p> <p>Yellow Flashing Strobe light is located on west side of Valcam load out facility and on both sides of load out at Skyline. Warning light will be activated when coal chute is extended, or released from locked secured position. Trains must stop short of loading facility when warning light is activated.</p>
Empty space for additional instructions